



COPPER SPILLWAY BOWL BUNDLE INSTALL GUIDE

Use this sheet as a guide for any Copper Spillway Bowl Bundle installation. We've prepared a list of all potential tools and supplies you will need to complete a successful Copper Spillway Bowl Bundle installation.

ESTIMATED INSTALL TIME:

Less than a day based on artistry and complexity of project

BASIC STEPS:

1. Prepare the base and the wall for the spillway
2. Place preformed flexible basin, flexible liner and bulkhead fitting
3. Continue to build wall and cap the columns
4. Fill with water, check all connections
5. Complete plumbing and install the Copper Bowl
6. Plug in water feature and enjoy!

*For detailed install instructions please refer to instruction manuals provided with each product or installation video on our website and YouTube.

ATLANTIC-OASE PRODUCT:

- Copper Spillway Bowl Project Bundle

*Please visit atlanticwatergardens.com and navigate to products to determine part numbers and product options

TOOLS & SUPPLIES:

- Markout paint
- Tape measure
- 2' and 4' levels
- Straight 2x4
- Wheelbarrow
- Shovel
- Tamper
- Lump hammer or mallet
- Grinder or chisel
- Screw driver or nut driver
- Tubing cutters or PVC saw
- Stone
- Construction adhesive
- Screenings or crushed lime stone
- Landscape block adhesive