



Plumbing Instructions FKHBB - 92709

For tandem Bowls with Pedestal, install the $1\frac{1}{2}$ " male thread by slip elbow (threaded street 90) in the center inlet of the larger, lower Bowl. Cut a 24" piece of $1\frac{1}{2}$ " flex PVC and glue into elbow. Glue a $1\frac{1}{2}$ " slip x slip x slip tee and $1\frac{1}{2}$ " street 90 onto the 24" pipe as shown. Glue $1\frac{1}{2}$ " x 1" slip reducing bushings into the tee and elbow as shown. Set assembly on Eco-Rise.

Install a $1\frac{1}{2}$ " male thread x slip adapter (male adapter) in the center inlet of the Spillway Bowl, then glue a $1\frac{1}{2}$ " x 1" slip reducing bushing into the male adapter. Set the Bowls and Pedestal in position. Measure the approximate distance from the center of the Spillway Bowl to the Pump Vault and add 12". Cut a piece of 1" flex pipe and glue into the reducing bushing.

